Installation manual for the PetSoft S2 GPS tracker, version H1

(abridged version v. 1.01)

Tracker: S2 H1 | Kit: Standard E H1



Basic recommendations:

- GPS tracker power supply connected "before the ignition" – it can be connected directly to the battery
- No **metal components** above the GPS tracker
- The GPS tracker should be positioned with the label **"THIS SIDE UP" ("TA STRONA DO GÓRY")** facing upwards (open sky) **(important)**
- The enclosure is waterproof – IP67
- The arrow on the enclosure indicates the direction of vehicle movement

Description of cable colours and functions:

1. Red – tracker power supply before the ignition (+) (from +9V= to +24V=)
2. Black – ground (-)

Installing the GPS tracker in the vehicle – cable connection

To correctly install the PetSoft S2 tracker in the vehicle, you should:

- Place the tracker in the vehicle with the label **"THIS SIDE UP" ("TA STRONA DO GÓRY")** facing upwards
- Connect [ground] [power supply "before the ignition"]

Description of the meaning of the LEDs on the enclosure

A properly installed GPS tracker indicates its operation with LEDs. The blue LED must remain constantly lit, which means GPS satellites are visible. The red LED must flash every 2 seconds, which means the vehicle's position signal is being sent to the server. Any other LED behaviour indicates the GPS tracker is not functioning correctly.

Start-up

To start the device, connect the power supply to the indicated wires. Then log in to your Monitoring-GPS.net account and check the vehicle's visibility on the map.