Installation manual for the PetSoft S2 GPS tracker, H2 version

(abridged version v. 1.01)

Tracker: S2 H2 | Kit: Standard E H2



Basic recommendations:

- GPS tracker power supply connected "before the ignition" – it can be connected directly to the battery
- No **metal elements** above the GPS tracker
- GPS tracker positioned with the label **"THIS SIDE UP"** facing upwards (open sky) **(important)**
- The casing is waterproof – IP67

Description of cable colours and functions:

1. Red – tracker power supply before the ignition (+) (from +9V= to +24V=)
2. Black – ground (-)
3. White – permanent positive after ignition (+)

Installing the GPS tracker in the vehicle – connecting the cables

To correctly install the PetSoft S2 tracker in the vehicle, you should:

- Place the tracker in the vehicle with the label **"THIS SIDE UP"** facing upwards
- Connect [ground] [power supply "before the ignition"] [positive after ignition]

Description of the meaning of the LEDs on the casing

A correctly installed GPS tracker indicates its operation with LEDs. The blue LED must be constantly lit, which means GPS satellites are visible. The red LED must flash every 2 seconds, which means the vehicle's position signal is being sent to the server. Any other behaviour of the LEDs indicates incorrect operation of the GPS tracker.

Start-up

To start the device, connect the power supply to the indicated wires. Then log in to your Monitoring-GPS.net account and check the vehicle's visibility on the map.