Installation manual for the PetSoft S2 OBD GPS tracker – basic version

(abridged version v. 1.03)

Tracker: S2 OBD | Kit: Standard OBD



Basic recommendations:

- No **metal elements** above the GPS tracker
- Protect from moisture – the casing is not waterproof.
- Do not attach the GPS tracker to metal elements of the vehicle body.

Installation description:

Insert the device into the OBD 2 socket in the car.

Installation of the GPS tracker in the vehicle

To correctly install the PetSoft S2 OBD tracker in the vehicle, you should:

- Insert the device into the OBD 2 socket in the car.

Description of the meaning of the LEDs on the casing

A correctly installed GPS tracker indicates its operation with LEDs. The blue LED must remain constantly lit, which means GPS satellites are visible. The red LED must flash every 2 seconds, which means the vehicle's position signal is being sent to the server. Any other behaviour of the LEDs indicates incorrect operation of the GPS tracker.

Start-up

To start the device, connect power to the indicated wires. Then log in to your Monitoring-GPS.net account and check the vehicle's visibility on the map.